



- [IC2262/2272 4-Channel Wireless Receiver Module Kits /w Remote](#)

### Control 4 Keys


Physical map:



Wiring Diagram:



Physical :



Button corresponding order:

- A -- Key 3
- B -- Key 1
- C -- Key 4

D -- Key 2

Press 'A' button, D3, and VT is high, the corresponding LED light once again.

Hold down the 'A' key, D3, and VT is high, the corresponding LED is lit.

Continuously press the 'A' key, the first time will flash once, and then does not shine.  
Stop for a moment and press to continue lit.

While holding down the "AB" key, D1 and D3 as well as VT corresponding LED lit simultaneously.

Four key while holding down the "ABCD", all lights lit simultaneously.